




SCAN

to watch video instructions




SCP-EasyFiber™

LC Type Fiber Optic Connectors - UPC (standard)  
For Duplex Zip Single Mode & Multimode Cable




**Insert the boot on the tight buffer.**

Insert the connector boot onto the cable




**Strip the 2.0mm cable so that there is about 50mm exposed.**

Strip outer jacket about 50mm to reveal 900-micron fibers



**According to the specifications on the packing bag, mark the cable jacket.**

Using the label, measure from the end of the buffer and make a mark between the 250µm and 125µm section



**Strip off the tight buffer and coating with a cable stripper.**

Strip the buffer to the mark using the middle hole, then the small hole on the stripper in short increments



**Cut the fiber to a length of 10mm with a cleaver.**

Cleave your fiber strand to 10mm from the mark



**Strip off the UV coating.**

Strip the remaining 20mm of buffer using the middle hole on the stripper




**Put some alcohol on a piece of gauze and clean the bare fiber.**

Clean any impurities from your cable using alcohol and a lint-free cloth



**When the wire bends up, it is fully inserted.**

Insert the fiber into the connector body until the strand meets resistance and bows slightly




**Take off the jig on the bottom of the connector body.**

Remove the connector jig




**Push the button on the top of the body.**

Lock the fiber inside the connector by pressing the amber button



**Screw the boot tightly closed, and cut off the exposed yarn.**

Screw the boot onto the connector body and trim any exposed Kevlar yarn



**Put the jig on the bottom of the body.**

To remove or re-terminate the connector, simply unscrew the boot and replace the jig